
Classic Series

F114-2 (Globe)
F1114-2 (Angle)

Operation

The Watts ACV Rate-of-Flow Control Valve with Pressure Reducing Feature is designed to automatically limit flow rate to a constant, adjustable, maximum, and reduce a fluctuating higher upstream pressure to a constant lower downstream pressure. In most applications, the Pressure Reducing function will be secondary to the primary Flow Control Function.

The flow control action of the valve is controlled by a normally open, differential control pilot designed to: 1) Open (allowing fluid out of the main valve cover chamber) when the differential pressure across the orifice plate is below its adjustable set point, and, 2) Close (allowing fluid to fill the main valve cover chamber) when the differential pressure across the orifice plate is above its adjustable set point. A decrease in differential pressure causes the valve to modulate towards an open position, increasing flow rate. An increase in differential pressure causes the valve to modulate towards a closed position, decreasing flow rate.

The pressure reducing action of the valve is controlled by a normally open, pressure reducing pilot designed to: 1) Open (allowing fluid out of the main valve cover chamber) when downstream pressure is below the adjustable setpoint, and 2) Close (allowing fluid to fill the main valve cover chamber) when downstream pressure is above the adjustable setpoint. A decrease in downstream pressure causes the valve to modulate toward an open position, raising downstream pressure. An increase in downstream pressure causes the valve to modulate toward a closed position, lowering downstream pressure.

NOTE: Please specify desired flow rate prior to ordering.

Installation Guidelines

- Prior to installation, flush line to remove debris.
- Install valve horizontally “in line” (cover facing UP), so flow arrow matches flow through the line. Avoid installing valves 6” or larger vertically. Consult factory **prior** to ordering if installation is other than described.
- Install inlet and outlet isolation valves. **NOTE:** When using butterfly valves, insure disc does not contact control valve. Damage or improper valve seating may occur.
- Provide adequate clearance for valve servicing and maintenance.
- Install pressure gauges to monitor valve inlet and outlet pressure.

Other Watts ACV Rate-of-Flow Control Valves

F114 / F1114	Rate-of-Flow Control Valve
F114-1 / F1114-1	Rate-of-Flow Control Valve with Solenoid (On-Off) Feature
F114-3 / F1114-3	Rate-of-Flow Control Valve with Hydraulic Check Feature
F114-8 / F1114-8	Rate-of-Flow Control Valve with Pressure Sustaining Feature