



BACKPRESSURE SUSTAINING VALVE with HYDRAULIC CHECK FEATURE

01/05

Mustang Series

M116-5 or M6116-5 (Globe)
M1116-5 or M61116-5 (Angle)

Operation

The Watts ACV Combination Backpressure or Sustaining Control Valve with Hydraulic Check Feature is designed to permit flow when upstream pressure is above the adjustable setpoint of the control pilot, and throttle toward closed when upstream pressure falls below the adjustable setpoint, and close drip-tight when downstream pressure becomes greater than upstream pressure.

It is controlled by a normally closed control pilot designed to: 1) Open (allowing fluid out of the main valve cover chamber) when upstream pressure is above the adjustable setpoint, and, 2) Close (allowing fluid to fill the main valve cover chamber) when upstream pressure is below the adjustable setpoint. An increase in upstream pressure causes the valve to modulate toward an open position. A decrease in upstream pressure causes the valve to modulate toward a closed position.

If downstream pressure becomes greater than upstream pressure, downstream pressure is admitted to the main valve cover chamber, closing the valve and preventing reversal of flow. Normal backpressure or sustaining operation resumes when upstream pressure exceeds downstream pressure.

When the valve is installed “in line” on the **discharge of a pump**, it acts as **Backpressure Control Valve**. When pump discharge pressure falls below the pilot setting, the valve modulates toward a closed position, increasing **backpressure** against the pump. The valve should be specified to include the optional **opening speed control** when used for Backpressure applications.

When the Model valve is located “in line” **connecting two distribution zones**, the valve acts as a **Pressure Sustaining Control Valve**. When pressure in the upstream zone falls below the pilot setting, the valve modulates toward a closed position, **sustaining** pressure in the upstream zone. The valve will close, if necessary, until upstream pressure is above the pilot setting. The valve should be specified to include the optional **opening speed control** and **position indicator** when used for Pressure Sustaining applications.



BACKPRESSURE SUSTAINING VALVE with HYDRAULIC CHECK FEATURE

01/05

Mustang Series

M116-5 or M6116-5 (Globe)
M1116-5 or M61116-5 (Angle)

Installation Guidelines

- Prior to installation, flush line to remove debris.
- Install valve horizontally “in line” (cover facing up), so flow arrow matches flow through the line. Avoid installing valves 6” and larger vertically. Consult factory **prior** to ordering if installation is other than described.
- Install upstream and outlet isolation valves. **NOTE:** When using butterfly valves, insure disc does not contact control valve. Damage or improper valve seating may occur.
- Provide adequate clearance for valve servicing and maintenance.
- Install pressure gauges to monitor valve upstream and outlet pressure.

Other Watts ACV Pressure Relief / Backpressure or Sustaining Control Valves

M116 / M6116	Pressure Relief / Backpressure or Sustaining Valve
M116-31 / M6116-31	Pressure Sustaining Valve with Solenoid (On-Off) Feature
M116-32 / M6116-32	Pressure Sustaining Valve with Solenoid (On-Off) and Check Features
M116-52 / M6116-52	Surge Anticipator and Pressure Relief Valve