



PRESSURE REDUCING VALVE with SURGE CONTROL FEATURE

01/06

910 Series

—Model— **910-11**
610-11

Operation

The AMES Model 910-11 / 610-11 Combination Pressure Reducing and Surge Control Valve is designed to automatically reduce a fluctuating higher upstream pressure to a constant lower downstream pressure, and will quickly modulate toward a closed position if downstream pressure suddenly becomes greater than the desired regulated setpoint. The quick closing action prevents possible damaging high inlet pressure from passing through the valve to downstream piping. Normal regulating action is controlled by a normally open, pressure reducing pilot designed to: 1) Open (allowing fluid out of the main valve cover chamber) when downstream pressure is below the adjustable setpoint, and 2) Close (allowing fluid to fill the main valve cover chamber) when downstream pressure is above the adjustable setpoint. A decrease in downstream pressure causes the valve to modulate toward an open position, raising downstream pressure. An increase in downstream pressure causes the valve to modulate toward a closed position, lowering downstream pressure.

If downstream pressure suddenly becomes greater than the desired regulated setpoint, the normally closed surge control pilot opens and rapidly admits higher inlet pressure into the valve cover, increasing rate of valve closure. Normal pressure reducing operation resumes when downstream pressure decreases below the desired regulated setpoint.

Installation Guidelines

- Prior to installation, flush line to remove debris.
- Install valve horizontally “in line” (cover facing UP), so flow arrow matches flow through the line. Avoid installing valves 6” and larger vertically. Consult factory **prior** to ordering if installation is other than described.
- Install inlet and outlet isolation valves. **NOTE:** When using butterfly valves, insure disc does not contact control valve. Damage or improper valve seating may occur.
- Provide adequate clearance for valve servicing and maintenance.
- Install pressure gauges to monitor valve inlet and outlet pressure.
- If installation is subjected to very low flow or potentially static conditions, AMES recommends a pressure relief valve (1/2” minimum) be installed downstream of the Pressure Reducing Valve for additional system protection.

Other AMES Pressure Reducing Control Valves

910 / 610	Pressure Reducing Valve
910-01 / 610-01	Pressure Reducing Valve with Hydraulic Check Feature
910-15 / 610-15	Pressure Reducing Valve with Solenoid (On-Off) Feature
910-17 / 610-17	Pressure Reducing Valve with Return Flow Feature
910-48 / 610-48	Pressure Reducing Valve with Low Flow By-Pass
912 / 612	Pressure Reducing and Pressure Sustaining Valve
912-01 / 612-01	Pressure Reducing and Sustaining Valve with Hydraulic Check Feature