

# RATE-OF-FLOW VALVE with PRESSURE SUSTAINING FEATURE

01/0

## **Classic Series**

F114-8 (Globe) F1114-8 (Angle)

### Operation

The Watts ACV Rate-of-Flow Control Valve with Pressure Sustaining Feature is designed to automatically limit flow rate to a constant, adjustable, maximum, and sustain a minimum upstream pressure. The flow control action of the valve is controlled by a normally open, differential control pilot designed to: 1) Open (allowing fluid out of the main valve cover chamber) when the differential pressure across the orifice plate is below it's adjustable set point, and, 2) Close (allowing fluid to fill the main valve cover chamber) when the differential pressure across the orifice plate is above it's adjustable set point. A decrease in differential pressure causes the valve to modulate towards an open position, increasing flow rate. An increase in differential pressure causes the valve to modulate towards a closed position, decreasing flow rate.

The normally closed sustaining pilot remains open when upstream pressure is above the adjustable setpoint, and modulates toward a closed position if upstream pressure falls below the setpoint. As the sustaining pilot closes, fluid is directed into the main valve cover chamber, allowing the valve to modulate toward a closed position, raising upstream pressure. Normal flow control operation resumes when upstream pressure is above the sustaining pilot setpoint.

NOTE: Please specify desired flow rate prior to ordering.

#### Installation Guidelines

- Prior to installation, flush line to remove debris.
- Install valve horizontally "in line" (cover facing UP), so flow arrow matches flow through the line. Avoid installing valves 6" or large vertically. Consult factory **prior** to ordering if installation is other than described.
- Install inlet and outlet isolation valves. **NOTE:** When using butterfly valves, insure disc does not contact control valve. Damage or improper valve seating may occur.
- Provide adequate clearance for valve servicing and maintenance.
- Install pressure gauges to monitor valve inlet and outlet pressure.

#### Other Watts ACV Rate-of-Flow Control Valves

F114 / F1114	Rate-of-Flow Control Valve
F114-1 / F1114-1	Rate-of-Flow Control Valve with Solenoid (On-Off) Feature
F114-2 / F1114-2	Rate-of-Flow Control Valve with Pressure Reducing Feature
F114-3 / F1114-3	Rate-of-Flow Control Valve with Hydraulic Check Feature